
# **Complex**<sup>®</sup>

# INSTRUCTION MANUAL



# **3 Tier Aluminium Heated Drying Rack**

Model: DHHDR3

For domestic household use only.



#### **IMPORTANT** THESE INSTRUCTIONS SHOULD BE READ CAREFULLY AND RETAINED FOR FUTURE REFERENCE. **Note also the information presented on the appliance**

## CAUTION: FAILURE TO FOLLOW THESE INSTRUCTIONS MAY CAUSE INJURY AND/OR DAMAGE AND MAY INVALIDATE YOUR WARRANTY

Please read the operating instructions carefully before using your product for the first time and keep them in a safe place.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Cleaning and user maintenance shall not be made by children.
- **CAUTION:** Some parts of this product can become very hot and cause burns. Particular attention must be given where children and vulnerable people are present.
- Only allow to install at the distance of atleast 0.6m from bath and shower
- **DO NOT** use if there are visible signs of damage to the heated drying rack.
- **DO NOT** place the Drying Rack directly below a fixed socket outlet.
- The socket-outlet used to plug in the Drying Rack must be accessible at all times to enable the mains plug to be disconnected as quickly as possible if required.
- WARNING: Risk of fire Do not use this appliance connected through an extension lead or any external switching device such as a plug-in timer or remote control plug in adaptor. All heating appliances draw high current through the mains supply and any weakness in the design, connections or components in these devices can easily result in overheating of the connection points resulting in melting, distortion and even the risk of fire.
- **DO NOT** pull, lift, carry or move the appliance using the mains lead.
- **IMPORTANT:** If the mains lead of this appliance is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- In the event of a fault, unplug the appliance.
- Unplug the appliance when not required for long periods.
- This product is only intended for INDOOR RESIDENTIAL applications. DO NOT cover cord with carpeting, throw rugs, runners, or similar coverings.

- **DO NOT** route cord under furniture or appliances. Take care to position the cord away from traffic areas and where it will not be a tripping hazard.
- **DO NOT** operate the Drying Rack in an area with gasoline, paint or flammable liquids may come into contact.
- **DO NOT** insert or allow foreign objects to enter any openings in the Drying Rack, as this may cause an electric shock, fire or damage to the Drying Rack.
- **DO NOT** use this product outdoors.
- WARNING: Use the Drying Rack only as described in this manual. Any other use is not recommended by the manufacturer and may lead to damage or hazards.
- **WARNING:** This instruction leaflet belongs to the appliance and must be kept in a safe place. If changing owners, the leaflet must be surrendered to the new owner.



weather outdoors



Where small children may be left unattended





If the power cable wires are frayed or cut



If an extension lead may become overloaded



Where the power cable may be damaged



Where there is risk of fire or close to a naked flame



On a slope or

uneven surface

Where there is a risk of interference by foreign objects



This product is not made for DIY repair



Where it may be damaged by chemicals



of water falling on the unit

0-

# Specifications

Model no.	DHHDR3
Power supply	220-240V ~ 50Hz
Rated power	300W
Temperature	50°C
Warm-up duration	10 minutes
Bearing capacity	15kg, each tier 5kg
IP Rating	IP22
Weight (net)	4kg
Dimensions (w x d x h)	680 x 730 x 1430mm


For greater precision, please always refer to the rating label placed on the product.

# Assembly

# HOW TO ASSEMBLE THE HEATED DRYING RACK:

## Note: For first time use, cut the ribbons attached to the columns of the Heated Drying Rack

- Place the Heated Drying Rack on a dry level surface near an electrical socket, with plenty of space surrounding the Heated Drying Rack.
- 2. Open out the supports to a 90° angle.
- 3. Slide all the shelf support clips (found on the two thinner supports), until they are facing straight out.
- 4. Stand at the side of the Heated Drying Rack that has the on/off switch and open out the shelves, starting with the **BOTTOM** shelf first, then the middle and then the top.
- 5. Now use the shelf support clips to secure the shelf.



0

## HOW TO OPERATE THE HEATED DRYING RACK:

Ensure the Heated Drying Rack is folded out securely before loading it with laundry and switching it on.

- 1. Make sure your electricity supply matches the voltage shown on the ratings label, then plug in the Heated Drying Rack.
- 2. Press the On/Off button on the control panel. When the Heated Drying Rack is on, the red indicator light will turn on.
- 3. The Heated Drying Rack will warm up within 10 minutes.
- 4. Load clothes evenly across the surface to avoid the Heated Drying Rack tipping over.

Clothes should be damp, not soaking wet. Wring out all excess water first before loading. Do not overload the Heated Drying Rack. The maximum load of the Heated Drying Rack is 15kg.

- 5. When you have finished using the Heated Drying Rack, switch the unit off by pressing the On/Off button again and unplug. Leave to cool down completely.
- 6. To fold closed for storage purposes, start with the **TOP** shelf first, then middle then bottom. Proceed to fold the supports together so the Heated Drying Rack is folded flat.

# Cleaning

Over time, dust can accumulate on the Heated Drying Rack which can effect performance. It is recommended to clean the unit at least once a month.

- 1. Turn the Heated Drying Rack OFF and disconnect the appliance from the power supply.
- 2. Remove any dust build up with a soft brush or vacuum cleaner with a soft brush attachment.
- 3. Wipe the outer surface of the unit with a soft damp cloth. Mild detergent can be used for any stubborn marks.

### IMPORTANT

The ON/OFF switch and other parts must not come into contact with water or any other liquids.

#### Storage

If the unit is not in use for an extended period of time, after cleaning please:

- Ensure the Heated Drying Rack is OFF and remove plug from the power outlet.
- Cover the unit and store it upright in a location where it will not receive direct sunlight. IMPORTANT NOTE: Prolonged exposure to direct sunlight will discolour the unit.

0

## Maintenance

If the unit fails to operate efficiently, is broken or other problems arise, unplug and do not operate. Ask for advice by calling your local after sales service agent or the Customer Care Centre on 1300 556 816 (AU) / 0800 666 2824 (NZ).

## Warranty

Please refer to the warranty card in the box for warranty information. For any troubleshooting advice, please contact the relative Customer Care Centre below.

#### Glen Dimplex Australia Pty Ltd

8 Lakeview Drive, Scoresby 3179, Victoria Australia Ph: 1300 556 816

#### **Glen Dimplex New Zealand Ltd**

38 Harris Road, East Tamaki, Auckland 2013 New Zealand Ph: 0800 666 2824



Recycling: Do not dispose of electrical appliances as unsorted municipal waste. Use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the ground water, polluting the food chain and damaging health and well-being.

# Notes



•



Customer Care: 1300 556 816 seasonal.support@glendimplex.com.au www.dimplex.com.au

Supplied by Glen Dimplex Australia 8 Lakeview Drive, Scoresby, Victoria, 3179

© Glen Dimplex Australia. All rights reserved. Material contained in this publication may not be reproduced in whole or in part, without prior permission in writing of Glen Dimplex Australia.